

# BACKRACK™

FUNCTION AND STYLE FOR TODAY'S TRUCKS

## Application Chart

YEAR/MAKE & MODEL	BACKRACK	BACKRACK (With Toolbox)	SAFETYRACK	SAFETYRACK (With Toolbox)	REAR BAR	TOOLBOX BRACKET <i>If sold separately. No hardware.</i>
<b>CHEV / GMC</b>						
2007-09 SILVERADO / SIERRA ( NEW BODY )	10519	10519 TB	10500 + 30119	10500 + 30119 TB	11519	91010
1999-07 SILVERADO / SIERRA, CLASSIC	10509	10509 TB	10400 + 30109	10400 + 30109 TB	11509	91010
1988-98 FULLSIZE CK SERIES	10503	10503 TB	10400 + 30103	10400 + 30103 TB	11503	91010
1968-87 FULLSIZE CHEV, GMC	10504	10504 TB	10400 + 30103	10400 + 30103 TB	11504 C	91010
2004-09 COLORADO / CANYON	10316	10316 TB **	10200 + 30116	10200 + 30116 TB		91010-C
1985-2005 S10, S15 COMPACT	10312	10312 TB **	10200 + 30113	10200 + 30113 TB		91010-C
<b>DODGE</b>						
2009 DODGE RAM 1500 ( NEW BODY )	10527	10527 TB	10400 + 30127	10400 + 30127 TB	11527	91010
2002-08 DODGE RAM FULLSIZE	10517	10517 TB	10400 + 30117	10400 + 30117 TB	11517	91010
1994-01 DODGE RAM FULLSIZE	10507	10507 TB	10400 + 30107	10400 + 30107 TB	11507	91010
1963-93 DODGE RAM FULLSIZE	10504	10504 TB	10400 + 30103	10400 + 30103 TB		91010
2005-09 DAKOTA	10314	10314 TB **	10200 + 30113	10200 + 30113 TB		91010-C
1987-04 DAKOTA	10313	10313 TB **	10200 + 30113	10200 + 30113 TB		91010-C
<b>FORD</b>						
1999-09 SUPERDUTY F250, 350	10501	10501 TB	10300 + 30201	10300 + 30201 TB	11501	91011
2004-09 F-150 6.5 & 8 FT BEDS	10512	10512 TB	10500 + 30112	10500 + 30112 TB	11512	91013
2004-09 F-150 5.5 FT, SUPERCREW	10512 SC	10512 SCTB	10500 + 30104	10500 + 30104 TB		91010-C
1997-03 F-150 6.5 & 8 FT BEDS	10502	10502 TB	10400 + 30102	10400 + 30102 TB	11502	91012
1997-03 F-150 5.5 FT, SUPERCREW	10502 SC	10502 SCTB	10400 + 30104	10400 + 30104 TB		91010-C
1975-96 F-150, F250 8 FT BED	10506	10506 TB	10400 + 30106	10400 + 30106 TB	11506	91010
1975-96 F-150, F250 6.5 FT BED	10505	10506 TB	10400 + 30105	10400 + 30106 TB	11506	91010
1993-2009 RANGER	10311	10311 TB **	10200 + 30111	10200 + 30111 TB	11310 R	91010
<b>TOYOTA</b>						
2008-09 TUNDRA FULLSIZE ( NEW BODY )	10518	10518 TB	10500 + 30118	10500 + 30118 TB	11518	91010
2005-09 TACOMA	10317 **	10317 TB	10200 + 30317	10200 + 30317 TB		91014
1995-07 TUNDRA	10508	10508 TB	10400 + 30108	10400 + 30108 TB	11508	91010
1995-04 TACOMA	10313	10313 TB **	10200 + 30113	10200 + 30113 TB		91010-C
1993-98 T-100	10508	10508 TB	10400 + 30108	10400 + 30108 TB		91010
<b>MAZDA</b>						
1993-09 MAZDA B SERIES	10311	10311 TB **	10200 + 30111	10200 + 30111 TB	11310 R	91010
<b>NISSAN</b>						
2004-09 TITAN, FULLSIZE	10511	10511 TB	10400 + 30511	10400 + 30511 TB		91010
2005-09 FRONTIER COMPACT	10314	10314 TB **	10200 + 30113	10200 + 30113 TB		91010-C
1987-04 COMPACT	10312	10312 TB **	10200 + 30113	10200 + 30113 TB		91010-C